

How to connect your new “PVR”

Step 1: Remove PVR and remote control from the carton and put the batteries in the remote control. Make sure that the power switch on the back corner of the PVR is “OFF” (bottom of the switch pushed in.) Have the remote control for you TV set handy.

Step 2: Put the PVR in location you will be using it (under TV, on top of TV).

Step 3: Find cable that is coming from the wall or up from the floor and disconnect it from where it is connected now. Remember where you removed it from. Connect this cable to the back of the PVR box on the TOP CENTER connector (it is labeled “SIGNAL IN”) which is labeled “A” in the diagram.

Step 4: Connect cable that was given to you with the PVR to the TOP LEFT connector (it is labeled “TV OUT”) which is labeled “B” in the diagram. Connect the other end of the cable just connected to where you disconnected the cable in step 3. Make sure ALL cables are finger tight and on correctly!

Step 5: Turn on your TV set and make sure that it is on channel 3 using the remote control for your TV set. Your TV MUST ALWAYS be on channel 3 for the Zapper to work. (You will NOT have a picture at this point.)

Step 6: Plug the PVR into a power source and turn it on with the switch in the back (top of switch in down).

Step 7: The PVR will boot up and if you have done everything correctly, you will be asked to pick a language. If you do not see this screen, please check the connection and go through ALL the previous steps.

Step 8: Make sure “English” is in yellow and click the “OK” button in the center of the remote control for the PVR (NOT the remote for the TV). The PVR will scan ALL the channels into itself. You will see channels that you are not supposed to get - this is normal and you won’t be charged for these. When it is finished scanning, it will ask you to save settings - please check that it says “185” channels. Make sure that the “YES” is highlighted and click the “OK” button in the center of the remote.

Remember: If you don’t see anything on your TV during this process - you have something conncted incorrectly. Make sure ALL connections are FINGER TIGHT. If you don’t have 185 channels - please call the office as there may be an in-house wiring issue

